

# MAX® Series Flexyoke Instructions



- 1** Snap Flexyoke into CTE single or double outlet faceplate or any other industry standard faceplate with cutout dimensions shown in the following table.


	mm	in.
Width	21.5 - 23.1	0.85 - 0.91
Height	36.3 - 36.8	1.43 - 1.45
Thickness	1.30 - 2.0	.053 - .079



- 2** Pull cable through Flexyoke opening. Mount faceplate assembly to wall box using screws included.



- 3** Terminate MAX module according to instructions provided with the module.



- 4** Snap icon into place on MAX module.

Snap MAX module into Flexyoke and label accordingly in space provided above the MAX module.

## To assist safe installations, comply with the following:

- A. Use caution when installing or modifying telecommunications circuits.
- B. Never touch uninsulated wire terminals unless the circuit has been disconnected.
- C. Never install this device in a wet location.
- D. Never install wiring during a lightning storm.

Communication Circuit  
Accessory Listed 5755



**Global Headquarters**  
Watertown, Connecticut USA  
Tel: (1) 866-548-5814

For a complete listing of our global offices visit our web site

 **SIEMON™**  
www.siemon.com